

Shiny Inking & Re-inking Instructions



1. Push the top of the stamp down lightly, about 1/4".
2. Push in on the two buttons on the sides of the stamp. This locks the stamp in place and positions the printing die away from the inkpad.
3. Use your finger or the end of a pen to push the stamp pad out. Note the imprint on your used ink pad so you can re-insert it in the same direction.
4. Carefully pull ink pad out of stamp and place pad face up and apply ink to surface. Do not over ink. It is best to apply a few drops of ink and re-apply if needed. Let the pad set for a least an hour before re-inserting into your stamp case. Press down on the case, and the locks will release.

Pre-inked replacement pads are also available.

