



Re-Inking MaxLight Stamps

- You must use **MaxLight Ink**, since another brand's formula will not mix with MaxLight and may damage your stamp.
- Remove the handle and add the ink as follows. If there are 2 ports, divide the ink evenly between the 2 ports.
 - Sizes 305, 325, PCM, PCL = 3-4 Drops
 - Sizes 115, 125, 145 = 4-6 Drops
 - Sizes 185, 265 = 6-8 Drops
 - Size 165 = 8-10 Drops
 - Size 245, 720 = 10-12 Drops
 - Size 225 = 12-14 Drops
 - Size 275 = 15-20 Drops
 - Sizes 700, 750, 800 = 20-24 Drops
- Replace the handle and allow to sit for 5 minutes.
- Occasionally, you may see lint or paper dust on your MaxLight surface. Simply place a piece of cellophane tape across the die of the stamp, rub your finger over the tape, then remove the tape. The tape will lift off the residue.